

Here's how to do it

Installation of C rail

Materials

- C-rail - complete set that includes brackets for ceiling or angle bracket mounting, stops and a number of slides
- Sliders (item no. 76782) - if additional sliders are desired
- Optional angle bracket for wall mounting (item no. 76597)
- Optional connector (item no. 76740)

Pssst ... You can also find our curtain guide on the website. Here you'll find lots of great tips and advice.



C-rail in ceiling with brackets



1. Measure how wide your window is. Add about 20% or 20-30 cm more to the window width. Cut the rail to fit your desired dimensions.



2. Start by clicking off the small button on the bracket.



3. Place the small button on top and press down until it clicks.



4. Push the bracket into the rail from the end, the brackets should be spaced max 50 cm apart



5. Decide how far from the wall you want the rail to be installed. Screw the rail directly into the ceiling.



6. Push the sliders into the rail. Place a stopper at each end of the rail and secure it by twisting the small eye.

C-rail on wall with angles

1. Measure how wide your window is. Add about 20% or 20-30 cm more to the window width. Cut the rail to fit your desired dimensions.



2. Start by clicking off the small button on the bracket.



3. Now insert the angle into the gap and secure it from below.



4. Push the bracket into the rail from the end, the brackets should be spaced max 50 cm apart



5. Determine how high above the window the rail should be installed. Mount the angle on the wall. NOTE: for wave curtains, it is recommended to use angles at minimum 7 cm.



6. Push the sliders into the rail. Place a stopper at each end of the rail and secure it by twisting the small eye.